



LEGEND

- AC AUTOMATIC CUTOUT
- MC MANUAL CUTOUT
- DS DISCONNECT SWITCH
- CONTACTOR COIL
- HEATING ELEMENT
- TR TRANSFORMER
- CONTACT NORMALLY OPEN
- FUSE

WARNING:
 Disconnect all supplies before working on this duct heater

IMPORTANT:
 Wire in according with electrical codes
 Use copper wire for 90°C minimum

NOTE:
 All wiring outside this frame are wiring by others

National Environmental Products Ltd 400 Lebeau, Montreal (QC) H4N 1R6
 T: (514) 333-1433 F: 333-3163

PROPRIETARY INFORMATION : THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION & IT'S PROPERTY OF N.E.P. LTD. THIS DOCUMENT AND THE INFORMATION IT CONTAINS SHALL NOT BE DUPLICATED OR USED IN WHOLE OR IN PART WITHOUT THE EXPRESS WRITTEN CONSENT OF N.E.P. LTD.

ELECTRICAL DRAWING

PART NUMBER: RTUEC4-30KW6003
PROJECT NAME: RTUEC
CUSTOMER NAME: CAPTIVE AIRE, INC.