



LEGEND

- AC AUTOMATIC CUTOFF
- MC MANUAL CUTOFF
- PDN AIR FLOW SWITCH
- DS DISCONNECT SWITCH
- CONTACTOR COIL
- HEATING ELEMENT
- TR TRANSFORMER
- CONTACT NORMALLY OPEN

○-□-○ FUSE
 Control 24V: RED WIRE
 Power: BLACK WIRE

WARNING:
 Disconnect all supplies before working on this duct heater

IMPORTANT:
 Wire in according with electrical codes
 Use copper wire for 90°C minimum

NOTE:
 All wiring outside this frame are wiring by others